

How to Measure for Curtains

Measuring Curtain Panel Width

A. Curtain Rod Installed

Step 1: Measure the curtain rod width

Step 2: Calculate the total curtain fabric width you need (for the whole window) by using **curtain rod width x 1.5 (regular headers) to 2 (any pinch pleat headers)**. You can always change this number based on your preference.

- For example if your curtain rod width is 90 inches, the total curtain fabric width would be $90 \times 1.5 = 126$ "
- We recommend 1.5 for most cases but you can adjust the number depending on how much fabric / how full you wish the final look to be (higher number = more fabric / fuller)
- If you're unsure, consult with our customer services team

Step 3: Divide the total curtain fabric width by the number of curtain panels on the rod to get the final width for one single curtain panel.

- For example: if you want a pair of curtains panels, divide the total curtain width by half.
 $126 / 2 = 63$, 2 panels each 63 wide.

B. Curtain Rod Not Installed

Step 1: Measure the width of your window

Step 2: Calculate the approximate width of your rod by adding 6" per side (12" in total) to the window width

For example if your window width is 78", by adding 6" to both ends your potential curtain rod width would be $78 + 6 + 6 = 90$ "

Step 3 & 4 : Same method as Curtain Rod Installed Section

Measuring Curtain Panel Length

Step 1: Mark the starting point for your curtains

The starting point of the length measurement is based on where your rod / railing is placed. Or where you prefer to place it.

Note: for grommet headers, please take into account the extra 0.4 inches of fabric above the grommets

Step 2: Decide the ending point for your curtains

We recommend the three curtain length types below for our custom curtains:

Floor length (curtains that meet the floor):

To achieve floor length, measure from that starting point to the floor.

Trouser Break

The trouser break length means curtains extends to the floor a little bit like trousers drape on to shoes. Measure from the starting point to the floor and add 2 inches to create a break in the fabric.

Puddle Length

Curtain fabric is a bit longer and will slightly puddle on the floor. To achieve puddle length, measure from the starting point to floor and add 6-10 inches.